

### TWIN PUSH BUTTON SWITCHES

(with plastic bracket)

Description	Ordering code
Both Red & Green buttons flush type 'O' & 'I' Marked	<b>PCB5- EB832</b>



Description	Ordering code
Red projecting type with 'O' mark Green flush type with 'I' mark	<b>PCB5- EB842</b>



### ILLUMINATED TWIN PUSH BUTTON SWITCHES

(with plastic bracket)

Description	Ordering code
Red & Green both buttons flush type & with amber lens marked 'I' & 'O'	<b>PCB5-EBW 836</b>



Description	Ordering code
Red projecting type with 'O' mark Green flush type with 'I' mark with amber lens	<b>PCB5-EBW 846</b>



Plastic Bracket not shown in the Picture

### LED MODULE PILOT LIGHTS

Type	Description	Ordering code
A	Pilot Light Head	<b>PB5-EVO ( )</b>
B	Led Holder with Led & Plastic Bracket	<b>PCB5-EWM( )6 #</b>
C	Assembly	<b>PCB5-EWVM( )6 #</b>



A



B



C

Add following suffixes in the ordering code for colour & voltage.

( ) 1 = White, 3 = Green, 4 = Red, 5 = Yellow, 6 = Blue

# 24, 110, 220 V AC & 24, 110, 220 V DC